

# Noise restrictions for departing aircraft at Höganäs aerodrome

## Non based aircraft

Maximum noise level according to aircraft noise certificate issued in accordance with ICAO annex 16 chapter 6 or chapter 10

		15 MAY - 31 AUGUST					
		Runway 06,14,24			Runway 32		
dB(A) Lmax	Mon-Thu			Fri-Sun			
	06-18	18-22	22-06	06-18	18-22	22-06	
Lmax ≤70 dB(A)	[Green]			[Green]			
Lmax >70 dB(A)	[Green]			[Green]	[Yellow]	[Yellow]	

  

		15 MAY - 31 AUGUST					
		Runway 32			Runway 32		
dB(A) Lmax	Mon-Thu			Fri-Sun			
	06-18	18-22	22-06	06-18	18-22	22-06	
Lmax ≤70 dB(A)	[Green]	[Yellow]	[Yellow]	[Green]	[Yellow]	[Yellow]	
Lmax >70 dB(A)	[Yellow]	[Yellow]	[Orange]	[Yellow]	[Yellow]	[Orange]	

		1 SEPTEMBER - 14 MAY					
		Runway 06,14,24			Runway 32		
dB(A) Lmax	Mon-Thu			Fri-Sun			
	06-18	18-22	22-06	06-18	18-22	22-06	
Lmax ≤70 dB(A)	[Green]			[Green]			
Lmax >70 dB(A)	[Green]			[Green]	[Green]	[Yellow]	

  

		1 SEPTEMBER - 14 MAY					
		Runway 32			Runway 32		
dB(A) Lmax	Mon-Thu			Fri-Sun			
	06-18	18-22	22-06	06-18	18-22	22-06	
Lmax ≤70 dB(A)	[Green]			[Green]			
Lmax >70 dB(A)	[Green]	[Green]	[Green]	[Green]	[Green]	[Yellow]	



No restrictions



Maximum 1 departure per hour per aircraft



Departure only permitted for flight with different destination aerodrome

Landings always allowed. Restrictions only applies to departures

Restrictions only valid for aeroplanes, not applicable to helicopters or gyrocopters.

If performance permits, helicopters should depart runway 06 or 14 and arrive runway 24 or 32, alternative direct approach from east or southeast and depart directly towards east or southeast.